



This cartridge comes from the factory assembled and ready to install. Do not take it apart or adjust it, as this will affect the performance of the valve.

Este cartucho viene montado de fábrica y está listo para instalarse. No lo desarme ni lo ajuste porque esto afectará el rendimiento de la válvula.

Instructions

Tools Required: Adjustable Wrench, Screwdriver

1. Turn off water supply to faucet.
2. Remove Handle Screw (A) at top of handle and keep for re-use.
3. Remove Handle (B).
4. Remove Screw (C) and remove Temperature Handle (D).
5. Remove Escutcheon Plate (E) by loosening Set Screw (I).
6. Use adjustable wrench to unthread Bonnet Assembly (F). Remove and discard.
7. Grasp end of Cartridge (G) with adjustable wrench and pull straight out.
8. Insert replacement cartridge into Valve Opening (H) in faucet body. The red mark points up.
9. Install new Bonnet Assembly (F) over cartridge, placing plastic washer first, then metal washer. Tighten to faucet body with adjustable wrench.
Note: Do not overtighten.
10. Reinstall Escutcheon Plate (E) and attach with Set Screw (I). Attach Handles (D) and (B) using Screws (C) and (A).
11. Turn on water supply to faucet. Check for leaks.

Instrucciones

Herramientas necesarias: llave de tuercas regulable, destornillador

1. Cortar el suministro de agua al grifo.
2. Retire el tornillo para manija (A) en la parte superior de la manija y quárdelo para usarlo.
3. Quite la manija (B).
4. Retire el tornillo (C) y quite la manija temperatura (D).
5. Retire la placa del escudo (E) aflojando el tornillo de fijación (I).
6. Use una llave ajustable para desenroscar el conjunto del casquete (F). Retire y deseche.
7. Agarre el extremo del cartucho (G) con la llave ajustable y tire directamente hacia afuera.
8. Inserte el cartucho de repuesto en la apertura de la válvula (H) en el cuerpo de la llave de agua. La marca roja debe apuntar hacia arriba.
9. Coloque el nuevo conjunto del casquete (F) sobre el cartucho, poniendo la arandela de plástico primero y enseguida la arandela de metal. Apriete el cuerpo de la llave de agua con la llave ajustable.
Nota: No apriete de más.
10. Instale placa del escudo (E) y móntela con el tornillo de fijación (I). Coloque las manijas (D) y (B) utilizando los tornillos (C) y (A).
11. Conecte el suministro de agua. Revise si hay fugas.