




FITS MOST KITCHEN SINK SPRAY

CABEZA ROCLADORA PARA FREGADERO DE COCINA

Visit
DANCO.COM
for Easy D.I.Y. Solutions



Instructions

Tools Required: Adjustable Pliers

1. Use pliers to unthread nut (A) on old spray head (E). Remove old spray head (E) and retainer clip (C) from spray hose (B).
2. Place new nut (A) over spray hose (B) and secure with new retainer clip (C).
3. Place new washer (D) on spray hose (B) and thread nut (A) onto new spray head (E).

Instrucciones

Herramientas Requeridas: Llaves Ajustables

1. Use llaves ajustables para tuercas para desenroscar la tuerca (A) del cabezal antiguo de rociado (E). Retire el cabezal antiguo de rociado y la presilla de retén (C) de la manguera (B).
2. Coloque la nueva tuerca (A) en la manguera de rociado y asegúrela con la nueva presilla de retén (C).
3. Coloque la nueva arandela (D) en la manguera ya enrosque la tuerca en el nuevo cabezal de rociado (E).